





SYNC YOUR SOLE

Charge

USB cable - Mini USB Port Inside Shoes




Charging - LED will flash



Fully charged - LED will be solid




Turn on - Reset Sync Shoes
Hold inside button 3 seconds




Download and launch Sync Footwear App



Turn Bluetooth On 



Sync and Pair the shoes with the app



Full product details, technical support and App instructions



www.syncfootwear.com

